



Moby Home Phone Features and Functions



5001 To Access Voicemail (or *98)

***72 Forward Calls to a Different Number**

***73 Cancel Call Forwarding**

4565 Default Voicemail Password

VoiceMail Options

Note: To return to the Main Menu after selecting a Menu Item, wait ~5 seconds

1 - New Messages

- 1 - Save
- 2 - Repeat
- 3 - Forward
- 4 - Delete
- 5 - Next Message
- # - Finish

2 - Old Messages

- 2 - Repeat
- 3 - Forward
- 4 - Delete
- 5 - Next Message
- # - Finish

3 - Send Message

4 - Call forwarding

5 - Options

- 1 - Change Password
- 2 - Record Name

6 - Greetings

- 1 - Record Greeting
- 2 - Review Greeting
- 3 - Select Greeting

7 - Recover Deleted Recordings

Contact Moby at **844.986.6629** or email subscribers@getmoby.com

For more information visit GetMoby.com today